SCloud App User Manual(iOS version)

Version:1.2.6

Procedure:

- 1.Download the latest SCloud App from Apple AppStore:
 - iOS AppStore: https://itunes.apple.com/my/app/scloud-stay-secure/id1276094284?mt=8






SCloud

SCloud iOS QR code

2.Please allow the notification during the first time app installation to receive event notification.




2. Register or login to the SCloud App.



User can choose any login method below:

- 1) Google/Facebook Authentication
 - a) Sign in to gmail/facebook account:





- b) First Time Login(Registration) will require user to enter their app password.
- c) The app password is not the email password.




- d) Registration Successful.
- 2) User Name
 - a) User can login by user name even their account is register from the Google/Facebook Authentication.In this case, user name can be found in the registration email received during the registration and the login password is the app password.




b) User name registration


- i) Press "Register"
- ii) Request the authentication code by entering email address:



iii) Check the authentication code from the inbox of your email:



iv) Enter the 6-Digits Authentication Code



v) Enter the user name and password and press"Register" button.




vi) Registration Successful.

- 3. After login, the apps will redirect to the main page. The main page consist of:
 - 1. Device List
 - a. All the user's device will be shown here.
 - b. User can do the user management(invite/remove user).
 - c. User can do the device/user rename.
 - d. User can manage the device's notification member.
 - 2. Alarm Status
 - a. Alarm system real time status.
 - b. Remote Control(Away Arm/Home Arm/Disarm/Panic).
 - c. Zone Rename/Bypass.
 - 3. Event Log
 - a. Event History.
 - 4. Setting
 - a. Custom Notification for each device.
 - b. Alarm status auto/manual refresh.



4. Device Pairing

1. Press on "New Device" and select "New Device Setup"



a. LAN Module

- i. Select LAN from Device Setup.
- ii. Scan the QR code from the LAN module.
- iii. Done.

b. WiFi Module

- i. In order to pair the WiFi module, user have to connect to the WiFi module and choose the WiFi's SSID and enter the password.
- ii. Make sure the WiFi module is install outside the metal box.
- iii. Follow the instruction, hold the reset button of WiFi module for 10 seconds. Upon success, both LED on the WiFi module will on for 1 second, and left only "WiFi" LED on.




Hold Reset Button For 10 Seconds

- iv. If the LED on the WiFi module is blinking, it means user holds the reset button less than 10 second. Please power off and on the alarm panel and start again from step ii.
- v. Press "Go WiFi List" ,the apps will redirect to iOS WiFi setting page.Connect to the "USR-C215"



vi. Make sure the "USR-C215" is connected




vii. Go back to the SCloud app.



viii. Select WiFi SSID

- 1. Please lock and unlock the phone once there is no WiFi SSID shown in the setup page.
- 2. Green color indicates good WiFi signal strength.
- 3. Orange color indicates Medium WiFi signal strength
- 4. Red color indicates poor WiFi signal strength. Please choose a better install location.



ull Digi 🕏 10:09 AM **Device Setup** Device Setup Device Setup L1AP2 I 1AP2 WPA/WPA2 Mixed Signal:78 WPA/WPA2 Mixed Signal:78 WPA/WPA2 Mixed Signal:70 L1AP1 L1AP1 WPA2 TKIP Signal:66 WPA2 TKIP Signal:66 WPA2 TKIP Signal:62 DEMO_L1 DEMO_L1 DEMO_L1 WPA2 AES Signal:50 WPA2 AES Signal:50 WPA2 AES Signal:50 AA@WIFI WPA2 AES Signal:14 **Auto Connect** SSID:L1AP2 Type:WPA/WPA2PSK

Confirm

SSID:L1AP2 Pass:aanetwork2017

Proceed


Back

ix. Select "Auto Connect", enter correct WiFi password and press "proceed".

x. The device will be added to the device list after the setup.

Manual Network

xi. The device will show "online" within a minute after the setup.




- xii. If the device still showing offline after few minutes, please check:
 - If the LED on the WiFi module still on, means the WiFi password entered is incorrect, please start again from step iii. (No need to remove device from devices list)
 - 2. Network connection
- xiii. Done.

5. Remotely Control the alarm system

- User can remotely home arm/away arm/disarm/panic the alarm system by press the action button in the alarm status page.
 - o Pin code is required to arm/disarm the system.
 - Hold 3 seconds to activate the panic mode.




- User can bypass/unbypass/rename the zones by pressing the zone number.
 - User can only bypass the zone in disarmed mode.



6.Event History

User can view event history in the "Event Log".



7. Custom Notification

User can enable/disable and select custom ringtone for events.



Ringtone Type	Events
Info	Home Arm,Away Arm,Disarm,Keyswitch Arm/Disarm
Warning	AC Failed/Restore,Battery Failed/Restore,Panic Restore,Duress Restore
Panic	Zone Burglar,Panic,Duress,Medical alarm,Fire alarm