

Dahua AS1201E Door Access

Admin Code: your 8-digit programming code

CHANGE ADMIN CODE

[#][Admin Code][#] blue flashing
[0][#][4~8-digit New Admin Code][#]
[4~8-digit New Admin Code][#][*][*]

ADD CARD/Pin with UserID

[#][Admin Code][#] blue flashing
[1][#][UserID eg. 1~9999][#]
[optional: flash new card][#]
[optional: 4~6-digit-Pin][#][*][*]

Note: recommended to use the last 4-digit of the printed card number

DELETE one CARD

[#][Admin Code][#] blue flashing
[2][#][UserID eg. 1~9999][#][*][*]
Or
[2][flash card][#][*][*]

DELETE all CARDS

[#][Admin Code][#] blue flashing
[2][#][0000][#][*][*]

Door Release Time

[#][Admin Code][#] blue flashing
[4][#][1~255][#][*]

CHANGE DOOR OPEN MODE

[#][Admin Code][#] blue flashing
[3][#][0][#][*] allow card access only
[3][#][1][#][*] allow card+pin access
[3][#][2][#][*] allow UserID+pin access
enter [UserID][#][Pin][#] to open
[3][#][3][#][*] allow card, UserID+pin access

OTHERS

[5][#][0][#][*] controller
[5][#][1][#][*] reader
[6][#][0][#][*] door sensor disabled
[6][#][1][#][*] door sensor enabled
[9][#][000][#] back to default



0 *0000*

Supported by: www.ealarm.com.my



e8

Optional add on features:

- Door bell
- Contactless release button
- Door release thru phone APP
- remote control button